



## HTP Spryer

Section	- 10-30L/MIN
RPM	- 800-1200R/MIN
Start	- RECOILSTART

